Alpha Clock Five

– Firmware v. 2.0 –User Interface Guide

Page 1 of 2: Main Button Usage



	SNOOZE SET ALARM	ALARM ON/OFF SETTIME	+	_
Press	Snooze	Alarm: On/Off	Brightness: Increase	Brightness: Decrease
Press	Simultaneous press: Show date		-	
Hold	Show alarm time Adjust alarm time, using +/-	Adjust time, using +/–	-	-
Hold pair	Simultaneous press and hold (4 seconds): Show firmware version & Enter (or leave) LED test mode		Simultaneous press and hold (2 seconds): Enter (or leave) settings menu	



Alpha Clock Five

– Firmware v. 2.0 –User Interface Guide

Page 2 of 2: Settings Menu Guide

To enter or exit the settings menu: Press and hold both "+" and "-" buttons for several seconds.



